

# Manhattan Petite

ergonomic chair



## Manhattan Petite

ergonomic chair



Designed for those of smaller stature.  
Comfort and adjustability in all the right places!







**Manhattan Petite** ergonomic Chair  
Style 682800

seat size:	17" D x 18" W
seat height:	15"- 19"
seat depth:	adjusts 2.5" range
back size:	20" H x 20" W
back height:	adjusts 3.5" range
arm height:	7"- 9" high
arm width:	adjusts 2" range
weight capacity:	275 lbs.



## Manhattan Petite

*ergonomic chair*

### Standard Features:

- Dual adjustable arm rest (vertical and horizontal)
- Silhouette arm pads
- Ratchet execution backrest height adjustment mechanism on a 3" "J" shaped back upright
- Seat depth adjusting mechanism
- Fully upholstered back rest with inner edge upholstery protector
- Pneumatic seat height adjustment
- Large 26" reinforced base with five prongs
- 60mm high impact casters
- Contoured reinforced inner-structure
- Thoracic back foam
- Waterfall seat front
- Available in fabric and vinyl. Color options available online in a downloadable PDF in the seating section at: [calpia.ca.gov](http://calpia.ca.gov)




#### Optional Soft Casters for Hard Floor Surfaces

Minimizes slippage on hard flooring. Soft casters can be installed before delivery if chairs and casters are ordered at the same time.



See website for  
Recycled Content Certificate

*Fabric colors represented in this brochure may appear different than actual fabric colors.*



#### Seat Adjustment Levers: Right Hand Side of Chair

- A. Pull up for lift height adjustment
- B. Pull up to disengage seat slider. Push forward to increase seat depth; backwards to decrease.

#### Seat Adjustment Lever: Left Hand Side of Chair

- C. Push or pull forward to lock the seat and back in 4 positions with anti-kick safety feature. Push or pull rearward for free float control.



The Manhattan Petite is equipped with the "Self-Weighing" chair control that responds to torque requirements covering a wide range of users without the need for tension adjustment.

#### Back Rest Adjustment: Back Cushion

- D. To adjust the backrest height, slowly pull backrest up in 1/2" increments (clicks) with both hands while seated.

#### Arm Height Adjustment: Knob on side of chair arms

- E. To adjust the height of the chair arms, push and hold the button while moving the arm up or down. Release the button at the desired height.

#### Arm Width Adjustment: Lever underneath chair arm

- F. Push lever backward to release chair arm adjustment. Arms adjust outward up to 2 inches. Pull arm inward towards chair to narrow width. Push lever forward to lock into place.



For more information visit our  
online catalog at: [calpia.ca.gov](http://calpia.ca.gov)  
or contact CALPIA at: (916) 323-2419.