

PATRIOT

ergonomic seating



PATRIOT

ergonomic seating



ergonomic comfort and sleek design

PATRIOT

ergonomic seating

The Patriot chair is our newest task seating offering. With sleek styling and extraordinary comfort, the highback chair will look at home in any organization. Multiple functions, and well proportioned, the Patriot is the new standard for ergonomic affordable seating.

Features

- 4D adjustable arm pads; forward/back, in/out. Arm pads can pivot inward
- Height and width adjustable chair arms
- Contoured waterfall seat edge with reinforced inner structure
- Mesh back with height adjustable lumbar support
- High resilient memory foam combined with molded foam provides supreme comfort
- Easy to use control mechanism that allows user to adjust the seat height, seat depth, back tilt, and tilt tension
- Sturdy 5 star base with casters that provide mobility

Options

- Adjustable height headrest, 1 ½” range, overall 7” high x 13 ½” wide, curved
- Seat upholstery options: black mesh, fabric, crypton or coated upholstery
- See ordering information: calpia.ca.gov

PATRIOT chair specifications

seat size:	19”D x 20.5”W
seat height:	17” - 21” (4” Range)
seat depth:	19” - 21” (2” Adjust)
arm height:	5” - 8.5” High
weight capacity:	300lbs.
back size:	#682200 w/o headrest 24”H x 19”W #682201 w/ headrest 30”H x 19”W



WITHOUT HEADREST
Item #682200



WITH HEADREST
Item #682201



Lumbar Adjustment Support

Pull up on the outer tabs to raise, push down on the tabs to lower, click into desired position



Arm Pads

Pivot Adjustment:

To pivot, turn the entire arm pad inward.


4-Way Direction Adjustment:

A. Tab: push in tab, slide arm pad inward or outward. Release tab to set in place.

B. Button: push round button, slide arm pad forward or backward. Release to set in place.

Arm Height

C. Tab: lift the tab all the way up, hold, then adjust arm height to desired position. Release tab to set in place.



Height Adjustable Headrest

Slide front pad of headrest up or down to desired height.



Left Side Adjustments

A. Tilt Lock Knob: turn knob counterclockwise to lock; clockwise to unlock.

B. Seat Slider: while seated, push down on paddle, push seat pan forward. To increase depth, release paddle when set to desired position.

C. Arm Width Adjustment Lever: Lever underneath chair arms. Pull lever backward - entire arm adjusts outward up to 2". Pull lever forward - to lock arm into place.



Right Side Adjustments

A. Seat Height: to lower, lift up paddle while seated. To raise, take your weight off the seat, then lift up the paddle. Release paddle at desired height.

B. Tilt Tension Knob: to increase tension, turn knob right, towards + sign, to decrease tension, turn knob left, towards - sign.