



BOSTON 24/7

24 hour task intensive ergonomic chair



BOSTON 24/7

ergonomic chair



24 hour task intensive
ergonomic chair.



California Prison Industry Authority
560 East Natoma Street Folsom, CA 95630-2200
916.323.2419 • calpia.ca.gov





BOSTON 24/7 ergonomic chair

Style 680001

seat size:	18.5" D x 20" W
seat height:	14.5" - 21"
seat depth:	adjusts 2" range
back size (w/headrest):	28.5" H x 21.5" W
back size (w/o headrest):	20" H x 21.5" W
headrest adjustment:	2" range
arm height:	5.75" - 9"
arm width adjustment:	3.25" range
weight capacity:	350 lbs.



Optional Soft Casters for Hard Floor Surfaces

Minimizes slippage on hard flooring. Soft casters can be installed before delivery if chairs and casters are ordered at the same time.

BOSTON 24/7

24 hour task intensive ergonomic chair



Features:

- A. Optional headrest adjusts up/down to required height with a built-in coat hook.
- B. Breathable, innovative mesh fabric back allows air flow and flexibility. Designed to be comfortable in all temperatures.
- C. Polyurethane arm pads are reinforced with a 3/16" steel plate.
- D. Enersorb™ memory foam (found in the seating surface, lumbar support and optional headrest) conforms to your body when you sit and reverts to its natural form when you get up.
- E. Double sealed 2 stage gas lift travels 6 1/2" and features a 3mm thick inner tube with a 5 year product warranty.
- F. Five-prong base with anti-slip treads. 2" dual wheel carpet casters.
- G. Multi-functional armrests include height adjustment and horizontal (in/out) adjustment.
- H. Slow release synchronous knee tilt mechanism, complete with intuitive side tension control and integrated seat slider.
- I. Contoured lumbar pad is easily adjustable for height and depth personalized lumbar support and comfort.


BOSTON 24/7 CHAIR ADJUSTMENTS



A. Arm Height Adjustment
To raise or lower arm height, pull trigger in and move to desired position. Release trigger to lock into position.



B. Horizontal Arm Adjustment
For increased width, pull arm out from seat to desired position from bottom of arm. Push arm in to decrease width.



C. Height and Depth Lumbar Adjustment Pad
Move lumbar inwards to desired depth for increased lumbar support. Press button down to release or decrease support. To raise, lift lumbar to desired height and release. To lower lumbar, lift to top position.



D. Seat Slider
Pull lever bar up to unlock, move seat to desired position, release lever to lock into position.



E. Pneumatic Height Adjustment
To lower, turn the paddle while seated. To raise, turn paddle with your weight off seat.



F. Infinite Position Tilt Lock
To lock chair in position, turn paddle up; to allow free movement, turn paddle down.



G. Tension Knob
Turn clock-wise to increase tension, turn counter-clockwise to decrease tension.



H. Height and Pivot Adjustable Headrest (optional)
Pull headrest up or down, while seated, to desired height. To pivot angle to desired position tilt headrest backward to achieve desired angle.



Built-in coat hook.

H. Height and Pivot Adjustable Headrest (optional)



See website for
Recycled Content Certificate

C. Height and Depth Lumbar Adjustment Pad

Polyurethane arm pad.

A. Arm Height Adjustment

B. Horizontal Arm Adjustment

D. Seat Slider

G. Tension Knob

Five-prong base.



Contoured memory foam seat incorporates a waterfall design that gently slopes away from the legs, minimizing pressure on the thighs, promoting good posture.

For more information visit our
online catalog at: calpia.ca.gov
or contact CALPIA Sales at:
916.323.2419